



## Using a VCR with HTC Digital Cable

The Next Level Residential Gateway converts the digital signal to three video streams. These video streams are converted to TV RF Channels 5,7,and 12. HTC combines these video streams so that all three are available on any TV in the house. VCR's convert the video and audio to either Channel 3 or 4. To view a video tape or to set-up the VCR using the VCR's Front Panel or Remote, the TV to which it is attached, must be set to either Channel 3 or 4, which ever the switch on the back of the VCR is set to.

### To set-up the VCR for direct recording

1. Set TV attached to your VCR to Channel 3 or 4 as above using the remote control that came with your TV or TV front panel.
2. Using the VCR Front Panel Button or VCR Remote set VCR to Channel 5.
3. Using HTC's Cable Remote use "Guide" to Select the Channel to record or, if known, punch in the Channel Number on the remote.
4. Press appropriate Record Buttons on VCR Front Panel or Remote Control.
5. To watch other programs while recording, set TV to Channel 7 or 12 using TV Front Panel or TV Remote, then select program using the HTC Cable Remote with Guide or by directly entering the Channel number on HTC's Remote Control.

(more) →

800-457-2125  
halstadtel.com

  
HALSTAD TELEPHONE COMPANY

*How To Connect*

6. Be sure not to turn TV Off using the HTC Cable Remote as this will also turn off the Video Stream going to the VCR. You can turn off the TV using the TV Front Panel or TV Remote.

### **To set-up the VCR for timed recording**

1. Set TV attached to VCR to Channel 3 or 4 as above with the remote control that came with your TV or TV Front Panel.
2. Using the VCR Front Panel Button or VCR Remote, select Menu or Timed Recording.
3. Using VCR Remote set VCR to Channel 5, Time to Start, Time to End and Tape Speed.
4. Press appropriate Buttons on VCR Front Panel or VCR Remote to enable Timed Recording.
5. To watch other programs while recording, set TV to Channel 7 or 12 using TV Front Panel or TV Remote, then select program using the HTC Cable Channel 7 or 12. Remote with Guide or by directly entering the Channel Number.